ErgoPerfect. How To Build a Power Chair



Insert stem of back into back of mechanism attached to the seat. Loosen and tighten hand crank as necessary to insert stem and fix seat back position.



Insert bottom of cylinder into hole in the center of the star base.



Insert top stem of cylinder into hole at center of chair mechanism



Insert caster stems into sleeves in feet of the star base and you chair is complete!

info@ergomat.com

Tel. 1-440-282-4651

1.877.ERGOMAT.com Fax 800-357-2113

Rev. 11/1